

Auxiliary Controls

Windscreen wipers/washers

On right hand side of steering column

Lift up for 3 speeds

Pull towards you for rear wipers

Press button for washers

Side/Head Lights

Rotary switch on right hand side of dashboard

Turn clockwise

1st position – side lights

2nd position – headlights

Always drive on headlights – Main beam

Indicator arm – pull towards you

Dashboard warning light

Fog Lights

Rotary switch on right hand side of dashboard

Only works when lights are on – Pull out

1st position – front fog lights

2nd position – hi intensity rear fog lights

Dashboard warning light

Visibility must be less than 100 mtrs

Hazard Lights

Push switch in centre of dashboard

Operates all four indicators

Only use in emergency, stopping on motorways

DO NOT USE for illegal parking

Windows

Side windows – 2 switches on drivers arm rest

Up/down – both sides

Front/Back windows

Demist – 2 switches in front of gear lever

Gauges

Speedometer

Rev Counter

Temperature

Fuel